





2. Fit the new forge valve with the same orientation as the picture below, using t





5.



8. Remove the bottom of the air box by pulling upwards to release it from its rubber mounts.









